

# WinchRite by Sailology



Operating Manual  
and  
Information Guide

---

STATE OF CALIFORNIA RESIDENTS:

 **WARNING**

“Lithium-ion Batteries and/or products that contain Lithium-ion Batteries can expose you to chemicals including cobalt lithium nickel oxide, and nickel, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).”

**NOTE:**

WinchRite 12 volt charging is achieved using an onboard inverter or small 150watt inverter along with the A/C charger that was included with the unit. An inverter for this is available within our online store and is included as of 2022. For additional information go to: <https://winchhandle.com>



## Table of Contents

---

Before You Begin	3
Safety Tips	4
Standard Operating Procedures	5
Warranty Information	6
Technical Specifications	7

## Thank You for your Purchase

---

The team at Sailology thanks you for your purchase of the WinchRite™. We wish you many years of easy and safe sailing. Please be sure to read this manual carefully before use.

Your WinchRite™ box should contain one unit plus the following:

- > Quick charging device/100-240 volt AC-Shore power-1
- > Inverter for 12v Charging
- > Storage Tote Bag-1
- > Storage Holder-1
- > Proprietary 10mm drive winch socket - 2pcs / STD and OS sizes



## Before You Begin

---

WinchRite™ is designed to operate the winches of a sailboat in normal cruising conditions. It is not designed to eliminate an on-board manual winch handle. A manual winch handle should always be available to operate your winches.

**WinchRite™ should never be used to haul a person up a mast.** It is our opinion that any mast climbing is a very dangerous undertaking and should only be performed by a professional experienced rigging service. Serious injury or death can occur if mast hauling is not performed properly. A WinchRite™ is not approved for hauling a person up a mast.

WinchRite™ should be used by persons knowledgeable in sailing techniques and familiar with the boat rigging it is to be used upon. WinchRite™ will allow you to rotate winches in both directions; this allows for two speed winches to be operated as designed.

We recommend self-tailing winches as the best way to utilize the operation of your WinchRite™.

WinchRite™ will allow you to pull or haul sails up the mast and pull or haul-out sails that are furled.

Variable speed of the device will allow some degree of trimming of the sails. A standard winch handle may be needed for the fine tweaking or trimming of sails. WinchRite™ was designed to perform the heavy or tedious bulk task of hauling or pulling sail lines.

This device was inspired by the cruising community so that one may truly enjoy the cruising sailboat experience; it was not designed for racing and may not conform to some racing rules.

Although WinchRite™ has a rugged lighter-weight design, caution should be used when handling the device so as to prevent damage from dropping or impact.

## Sailing Safety Tips – Some ABC's

---

Sailing carries a degree of unpredictability due to sudden changes which occur on the water beyond a sailor's control. It may be very easy to injure your extremities such as hands and fingers when sailing. Additionally, sailboats are fastened with a large amount of equipment, such as winches, hooks, cleats and other devices that are necessary for sailing. All of this equipment may become hazardous at any given moment. A sudden wind gust, a wave or wakes can make this equipment an instant threat to your hands and fingers if they are in the wrong place at the wrong time. Below are some safety tips to help keep your hands and fingers in their rightful place.

**A-lways** pay attention! Be aware of what is happening around you at all times. Sudden wind shifts, waves and wakes from other boats can result in attitude changes of your sailboat. The more prepared you are for these types of changes, the better you will respond to them as they occur.

**B-efore** you grab look! Know where you're reaching and what you are grabbing. Know which parts of the boat are stable and safe to grab onto. Many hand and finger sailing injuries are a result of slips and falls, as someone loses their balance or their grip. Sailboats have many hazards inherent to the hardware; the important thing is identifying the safe grab areas before you actually need to know they're there.

**C-aution** should always be used! The use of sailing gloves is recommended and can be found in many sizes with full or partial hand and finger coverage. While sailing gloves cannot fully prevent the risk of a hand or finger injury, they do provide a degree of protection. In addition, they enhance your gripping, which helps with grasping wet surfaces or while making adjustments to rigging lines quickly and firmly. This can lower the chances of a painful rope-burn or a loose line on deck resulting in a hazardous trip and fall for conditions.



## Standard Operating Procedures

---

### Preparing the WinchRite and your rigging for use:

Fully charge your WinchRite battery utilizing the charger provided with this product. (USE ONLY THE APPROVED CHARGER) A red indicator light will appear during charging and turn green when charging is complete. Initial first charging should be very short time frame as all WinchRite™ units are tested and charged prior to delivery

After charging is complete install the provided specialty winch cog socket to the 10mm square drive area of the device. You are now ready to use your new WinchRite Cordless Winch Handle.

Load your winch with the line to be pulled in the standard manner. We recommend you utilize a greater portion of the winch drum with at least three wraps.

Rig your lines ensuring they run straight from the blocks to your winch without rubbing against anything that could prevent operation and/or cause damage to the line and/or hardware. Ensure you have used proper lubrication for any slide tracks or blocks.

Run the length of your lines through your hands to guarantee they are free of any twists or knots.

Lay the line in the open palm of your hand and begin wrapping it in a clockwise motion around the spool of the winch until there is a minimum of three wraps.

Keep your hand above the winch as you wrap, taking care not to wrap the line around your hand or fingers. Hold the line taut and free of slack so that it lies on top of itself, snug to the winch. Verify there are no overlaps or knots in the line.

Place WinchRite™ on the winch ensuring the cog of the device is dropped into the cap stand socket. Initially, just tap the power switch to confirm you are driving the winch in the intended direction. Begin winch operation to achieve your intended result.

WinchRite™ is designed to pull away from your hand operation as a safety precaution to prevent over-torque of the unit and your winch.

## Warranty Information

### One Year Limited Warranty

For a twelve (12) month period from date of purchase, subject to the terms and conditions herein after set forth, Sailology LLC reserves the right and option, at its sole discretion, to repair or replace defective equipment, parts or components.

This warranty does **not** apply to the following:

Defects or malfunctions resulting from failure to properly install or operate the unit in accordance with its standard operating procedures and normal sailing practices.

Defects or malfunctions resulting from abuse, accident or negligence. Any unit which is used for purpose(s) other than for which it was designed and manufactured.

Any unit which is damaged by conditions classified as "Acts of God."

\*\*\*\*\*

Use this online form for any and all warranty service:

<https://winchhandle.com>

Any unit to be serviced or replaced must be returned to Sailology LLC with freight prepaid. You will be instructed where to ship the device when contacting the company through the website.

Sailology LLC reserves the right to change or improve its products or any portion thereof without being obligated to provide such a change or improvement for units sold and/or shipped prior to same.

AFTER THE EXPIRATION OF THE TIME PERIOD OF THIS WARRANTY, THERE ARE NO WARRANTIES OF ANY KIND, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT SHALL SAILOLOGY LLC BE LIABLE OR RESPONSIBLE FOR ANY CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES RESULTING FROM OR RELATED IN ANY MANNER TO ANY SAILOLOGY LLC PRODUCT, PARTS OR SERVICE.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE FACE HEREOF UNLESS PURCHASED AS AN EXTENDED LENGTH OR REPLACEMENT AT THE TIME OF PURCHASE.



## Technical Specifications

---

Functional Weight:	6.2lbs
Maximum Torque:	110+nm
Internal Motor:	Brushless
Internal Lithium Ion Battery:	22.2v - 3.2ah
A/C Charger:	12v 3amp output
Cog Rotation-Direction / Two Speed Winch:	Dual-Reversible
Cog Rotation Speed:	0-120 RPM
Speed Control:	Variable Trigger
Drive Cog Socket:	Stainless Steel
Total Length– Handle To Nose:	15.0"
High Strength Plastic Alloy Housing:	PC/ABS-Composite
Internal Drive	Metallic Gearing
Non Skid:	Rubber Molded





***WinchRite***<sup>TM</sup>  
Cordless Winch Handle

Is a registered trademark of Sailology LLC  
COPYRIGHT Sailology LLC 2010-2021

For Tech Support Visit Link And Fill Out Form:  
<https://winchandle.com/tech-support-request>

